

Skifinder



### Select a family of skis by defining preferences!

1   Where do you ski?		Yes	No
Powder + Open Bowls	Freeride	<input type="checkbox"/>	<input type="checkbox"/>
Steeps + Trees	Freeride	<input type="checkbox"/>	<input type="checkbox"/>
Race Course	Racing	<input type="checkbox"/>	<input type="checkbox"/>
Groomed Runs	All-Mountain Cruise	<input type="checkbox"/>	<input type="checkbox"/>
	All-Mountain Carve	<input type="checkbox"/>	<input type="checkbox"/>
Park & Pipe	Park & Powder	<input type="checkbox"/>	<input type="checkbox"/>

Suggested Head ski category >>

---

### Narrow the field with skill assessment and style!

#### 2 | How well do you ski?

Competitor)  Expert)  Advanced)  Intermediate)  Novice)

Suggested Head ski model >>

---

### Clarify stability needs!

#### 3 | How fast do you ski?

Blazing I often pass other skiers  
 Fast I'm rarely passing or being passed by other skiers  
 Slow to Moderate Other skiers often pass me

### Head sizing chart

Weight	Height	Ski Length	Ski Length	Ski Length
		All-Mountain Cruise All-Mountain Carve Park & Powder Racing Giant Slalom* Junior	Racing Slalom*	Freeride Monster Line
10–13 kg 22–29 lbs		< 70 cm		
14–17 kg 30–38 lbs		70–80 cm		
18–21 kg 39–47 lbs		80–90 cm		
22–25 kg 48–56 lbs		90–100 cm		
26–30 kg 57–66 lbs		100–110 cm		
31–35 kg 67–78 lbs		110–120 cm		
36–41 kg 79–91 lbs		120–130 cm		
42–48 kg 92–107 lbs	< 148 cm < 4'10"	130–140 cm		
49–57 kg 108–125 lbs	149–157 cm 4'11"–5'1"	140–150 cm		150–160 cm
58–66 kg 126–147 lbs	158–166 cm 5'2"–5'5"	150–160 cm	150 cm	160–170 cm
67–78 kg 148–174 lbs	167–178 cm 5'6"–5'10"	160–170 cm	150–160 cm	170–180 cm
79–94 kg 175–209 lbs	179–194 cm 5'11"–6'4"	170–180 cm	160–170 cm	180–190 cm
≥ 95 kg ≥ 209 lbs	≥ 195 cm ≥ 6'4"	≥ 180 cm	170–180 cm	> 190 cm

\*Competitors please consider FIS regulations

### Locate the skier's height and weight in the columns.

#### When height and weight are on the same line

Blazing or fast skiers should select a length at the higher end of the given range.

Slow to moderate skiers should select a length at the lower end of the given range.

#### When height and weight are not on the same line

Blazing or fast skiers should select a length from the range closer to the bottom of the chart.

Slow to moderate skiers should select a length from the range closer to the top of the chart.

### For more information check out our Mount Head at head.com

Suggested Head ski length

Suggested Head ski model

